



Log Set Assembly



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.




Stocked at Depot

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
	Log Assembly		LOGS-NDI35	Y
1	Log 1		SRV2224-701	
2	Log 2		SRV2224-706	
3	Log 3		SRV2224-702	
4	Log 4		SRV2224-703	
5	Log 5		SRV2224-704	
6	Log 6		SRV2224-705	
7	Fireplace Termination Assembly		2205-012	
	Flex Pipe Handle		438-351	
	Gasket		2206-401	
8	Burner Assembly		2224-007	Y
9	Base Pan		2205-106	
10	Valve Assembly		Refer to valve page.	
11	Grate Assembly		2224-016	
12	Glass Door Assembly		GLA-2205	Y
13	Control Panel		2205-129	
14	Cord Assembly		2226-017	Y
15	Wire Assembly		2206-068	Y

Additional service part numbers appear on following page.

#10 Valve Assembly



IMPORTANT: THIS IS DATED INFORMATION. When requesting service or replacement parts for your appliance please provide model number and serial number. All parts listed in this manual may be ordered from an authorized dealer.



Stocked at Depot

ITEM	DESCRIPTION	COMMENTS	PART NUMBER	
10.1	Pilot Bracket		2206-105	
10.2	Pilot Assembly NG		2198-014	Y
	Pilot Assembly LP		2198-015	Y
10.3	Orifice NG (#33C)		582-833	Y
	Orifice LP (#50C)		582-850	Y
10.4	18" Flex Tube Assembly		530-302A	Y
10.5	Bracket		2205-128	
10.6	Valve Bracket		2205-146	
10.7	Flex Ball Valve Assembly		302-320A	Y
10.8	Valve NG		750-500	Y
	Valve LP		750-501	Y
10.9	Brass Connector	Pkg of 5	303-315/5	Y
10.10	Battery Pack		593-594A	Y
10.11	Wire Harness		593-590A	Y
10.12	Power Supply		593-593A	Y
10.13	Module		593-592	Y

Additional service part numbers appear on following page.

